

Belted Base Chute

Installation instructions:

1. Bolt the chamber extension onto the baler and set the length of the wagon hitch on the baler to put the hitch pin hole one inch behind end of the chamber extension.
2. Bolt the base chute into place. It should be a direct replacement for the one you have.
3. Set the length of the accumulator tongue to put the hitch pin 8" in front of the front edge of the base chute.
4. Finally, on level ground, fasten the belt plates to the pins on the side of the chute extension with enough tension on the belt to draw the center of the tensioner pulley to roughly 4" behind the centers of the other pulleys.

